

ERIT

An application for deliveries to BORIS

This is an introduction to the application ERIT that is based on Excel.

The application can create Excel templates with headers. When they are filled with data, they can be converted to MRN files (delivery files) for BORIS. The application can also convert MRN files to Excel files.

The start page for the application is shown below.



Handling

Click **Skapa Ny Excelmall** to start Excel where a blank template with headings will be created. An explanation about how to enter data into the cells can be found in the section **Columns** below.

Do not reorder columns or rename the **ERIT tab**. Save the Excel file with a name of your choice when your work is finished.

	A	B	C	D	E	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U
1	Unval	Inaktivering	Återlämna	FB-kod	Ritningsnummer	Bladnr	Dok.typkod	Version	Bladbenämning	Ver.datum	Formatkod	Förvarskategori	Affärskrets	Förstagivert	Tillhörighet (FBet)	Bildfilnamn	Överliggande ritningar	Ersätter: FB-kod+Ritningsnummer	Förrådbet.	Egen kommentar
2				SAAB	8-123456	1	RITN	A	VINKELPLÅT	4	200120				M1234-567890,	123456.pdf	SAAB,8-111222			

A short description appears for each column when hovering the mouse pointer above a heading.

It is possible to create rows in the Excel template for deactivating drawings as well as for returning drawings on loan. This is done by marking the **Inaktivering** and **Återlämna** columns respectively and entering the identity of the drawings.

Click **Skapa transfil från Excel** to create a MRN file (delivery file) from a saved Excel file. Before a MRN file is created, the rows in the Excel file are checked and any error descriptions are written into a cell on each row.

Click **Skapa Excel från transfil** to read an MRN file (delivery file) and create an Excel template filled with data from the file.

Columns

Urval	There is an option to only use a selection of rows when creating a MRN file. Enter 1 in this cell for these rows to select them. If this cell is empty for all rows, a MRN file is created for all rows containing image filenames, and for all rows related to deactivation and returning loans.
Inaktivering	Enter 1 in this column if the drawing on the row should be set as deactivated in BORIS.
Återlämna	Enter 1 in this column if the drawing on the row is on loan in BORIS and should be returned.
FB-kod	Company Letter Code of the drawing according to FMV's GoF. Mandatory.
Ritningsnummer	Drawing number. Enter up to 27 alphanumeric characters. Mandatory.
Bladnr	Sheet number with up to five digits. Mandatory.
Doktypkod	Document type code as specified for BORIS. Mandatory.
Version	Version of the sheet. Up to six characters can be entered, but it may be empty.
Bladbenämning	The designation of the sheet. Mandatory for new drawings and sheets.
Formatkod	Code specifying the size of the sheet. Allowed values are 0 to 4 (A0 to A4). Mandatory for new drawings and sheets.
Ver.datum	Date when the sheet was created according to the header of the drawing. Enter the date in YYMMDD format.
Försvarssekretess	Enter 1 in this column if the drawing is classified according to the Swedish Armed Forces.
Affärssekretess	Enter 1 in this column if the drawing is classified according to the supplier of the drawing.
Företagsinternt	Enter 1 in this column if the drawing only should be available in BORIS for special groups of users.
Tillhörighet (Fbet)	The Swedish Armed Forces number (beginning with M or F) for the equipment that the drawing describes.

Multiple numbers may be entered, and they must be separated by a comma.

Mandatory for new drawings. May be entered for deactivating drawings.

Bildfilnamn

Name of the drawing's image file.

Multiple image files may be specified for a drawing, for example files for PDF and Auto CAD. These file names are to be separated by comma.

Mandatory for new drawings.

Överliggande ritningar

FB code and drawing number for parent drawings. E.g. an assembly drawing can be a parent to a detail drawing. The two values are separated by a comma.

Multiple parent drawings can be specified. These must be separated with a comma.

Ersätter FB-kod + Ritningsnummer

FB code and drawing number for a drawing to be replaced by the row's drawing. The two values must be separated by a comma.

A replaced drawing will be deactivated in BORIS.

Förrådsbet.

Sometimes a drawing in itself has a number (beginning with M or F) in GoF. In that case it should be entered in this cell.

Egen kommentar

A place to write a comment. It will not be transferred to Boris.

An extensive description of all columns above can be found in the document **Delivery description Boris**. The document can be downloaded from FMV's website (Logistikportalen).